



Nova Filtration Technologies

VS SERIES

SINGLE CARTRIDGE FILTER HOUSING

FEATURES:

- Heavy Duty Stainless Steel Construction For Maximum Reliability & Durability
- Accepts Double Open End (DOE) Cartridges
- Available With 3/4" & 1" In-line Connections For Easy Installations
- Designed For Residential, Commercial & Light Industrial Applications
- Ring Nut Closure Allows Quick Cartridge Change-Outs
- Spring Loaded Knife Edge Seal Plate Provides Positive Sealing For Variable Length Cartridges
- Double Gasket Design Enhances Closure Seal
- Optional Gasket Materials Available for Compatibility With Most Fluids



SPECIFICATIONS:

- **Material of Construction:** Head/Shell: 304L Stainless Steel
Optional: 316L Stainless Steel
- **Maximum Allowable Pressure:** 300 PSI (20.7 Bar)
- **Maximum Allowable Temperature:** 200°F (93°C)
- **Connections:** Inlet/Outlet: 3/4" Or 1" FNPT
Drain Port: Petcock Or 1/4" Plug
- **Gaskets:** EPR
Optional: Buna N, Silicone & Viton

APPLICATIONS:

- Water
- Pulp & Paper
- Oil
- Chemicals
- Electronics
- Ink
- Paints/Coatings
- Coolants

BUILDING A PART NUMBER

VS-1	Cartridge Length	Pipe Size (FNPT)	Options	Gaskets
VS-1	1	6		
	9 3/4" - 10" = 1	3/4" = 6	Blank	EPR (Standard) = Blank
	19 1/2" - 20" = 2	1" = 8	BSP Thread = BSP	Buna N = B
			316 SS = 316	Silicone = S
			Drain Plug = PLUG	Viton = V

*Custom configurations may be available upon request